

### Copper Bonnet

| C&D Item No. | Size | Universal No | Pressure Rating | Pack qty |
|--------------|------|--------------|-----------------|----------|
| CD-108-04    | 1/4  | B1-4         | 60bar           | 10       |
| CD-108-06    | 3/8  | B1-6         | 60bar           | 10       |
| CD-108-08    | 1/2  | B1-8         | 60bar           | 10       |
| CD-108-10    | 5/8  | B1-10        | 60bar           | 10       |
| CD-108-12    | 3/4  | B1-12        | 60bar           | 10       |



### Copper Flare Washer

| C&D Item No. | Size | Universal No | Pressure Rating | Pack qty |
|--------------|------|--------------|-----------------|----------|
| CD-109-04    | 1/4  | B2-4         | 130bar          | 10       |
| CD-109-06    | 3/8  | B2-6         | 130bar          | 10       |
| CD-109-08    | 1/2  | B2-8         | 130bar          | 10       |
| CD-109-10    | 5/8  | B2-10        | 130bar          | 10       |
| CD-109-12    | 3/4  | B2-12        | 130bar          | 10       |



### Copper End Cap

| C&D Item No. | Size  | Pressure Rating | Pack qty |
|--------------|-------|-----------------|----------|
| CD-110-06    | 3/8   | 43.5bar         | 2        |
| CD-110-08    | 1/2   | 43.5bar         | 5        |
| CD-110-10    | 5/8   | 43.5bar         | 5        |
| CD-110-12    | 3/4   | 43.5bar         | 5        |
| CD-110-14    | 7/8   | 43.5bar         | 2        |
| CD-110-16    | 1     | 43.5bar         | 2        |
| CD-110-18    | 1 1/8 | 43.5bar         | 1        |
| CD-110-20    | 1 1/4 | 43.5bar         | 2        |
| CD-110-22    | 1 3/8 | 43.5bar         | 1        |
| CD-110-24    | 1 1/2 | 43.5bar         | 2        |
| CD-110-26    | 1 5/8 | 43.5bar         | 1        |
| CD-110-32    | 2     | 43.5bar         | 1        |
| CD-110-34    | 2 1/8 | 43.5bar         | 1        |
| CD-110-42    | 2 5/8 | 43.5bar         | 1        |
| CD-110-50    | 3 1/8 | 36bar           | 1        |



### Copper Flare Solder Adaptor Washers\*

| C&D Item No. | Size | Pressure Rating | Pack qty |
|--------------|------|-----------------|----------|
| CD-111-04    | 1/4  | 130bar          | 10       |
| CD-111-05    | 5/16 | 130bar          | 10       |
| CD-111-06    | 3/8  | 130bar          | 10       |
| CD-111-08    | 1/2  | 130bar          | 10       |
| CD-111-10    | 5/8  | 130bar          | 10       |
| CD-111-12    | 3/4  | 130bar          | 5        |



\* For use with CD-210 Series

